


The safety of this playmat **CHIPOLINO** and the materials used for its production is guaranteed and certified in test laboratories according to EN Standards.

INSTRUCTION MANUAL FOR PLAYMAT



PLEASE, READ THIS INSTRUCTION MANUAL CAREFULLY BEFORE USING THE PLAYMAT AND KEEP IT IN A SAFE PLACE FOR FUTURE REFERENCE.

This product is suitable for newborn babies aged up to 5 months. The playmat with both arches and toys stimulates baby's senses. It has only entertaining functions. This product is manufactured in accordance with requirements of Directive 2009/48/EC of European parliament and the Council regarding safety of toys. It is made of safe materials.


ATTENTION! Please, follow thoroughly the recommendations in this instruction manual! This will assure the safety of your child during the use of this product! Pay special attention to the warnings for safety, in order to prevent possible injuries to your child and to guarantee his safety!

INSTRUCTIONS AND WARNINGS FOR SAFE USAGE

1. **ATTENTION!** TO BE USED ONLY UNDER ADULT SUPERVISION!
2. **ATTENTION!** TO AVOID ENTANGLEMENT, REMOVE ARCH WITH TOYS WHEN BABY STARTS PUSHING ON HANDS OR KNEES OR STARTS RISING! **Such skills children acquire when they are aged around 5 months or up!**
3. This toy is intended only for domestic usage.
4. Do not place this playmat on elevated or uneven surfaces, when there is a child on it! Place it only on flat surfaces and far from stairs, heaters, pools or other dangerous places!
5. **ATTENTION!** KEEP THIS PRODUCT AWAY FROM FIRE! Be aware of the risk of open fire and other sources of strong heat, such as electric bar fires, gas fires, etc. that are in the near vicinity of the playmat.
6. Unpacking and fixing to be done only by an adult!
7. Do not place over the arch other toys, objects or cords. They can make the playmat unstable or fall over the child and cause entanglement and/or suffocation.
8. Regularly check all parts of the playmat, stitches, toys and stability of both arches to avoid injuries. Child must not have an access to small parts from the filling. If you find some damages, discontinue the usage until the damage is fixed or repaired.
9. Do not make any settings or repairs on both arches and toys, when there is a child on the playmat!

10. The safety of this product and the materials used in its production is guaranteed and certified with test reports. The safety is guaranteed by the producer only as the product is supplied. Each change can cause serious injuries.
11. Do not use the poly bag to carry babies, children or other products. This bag is not a toy and it is not intended for play.
12. Use the poly bag only by its purpose – to store or catty this playmat. It can be dangerous in case children have access to it. Keep it in safe place to avoid injuries or suffocation.

INSTRUCTION FOR ASSEMBLY THE ARCHES AND TOYS. CARE AND MAINTANANCE



Assemble both arches to the playmat via plastic clips. Make sure they are well fixed before usage. Plastic hooks on the toys can be opened, which makes them easy to attach and clean. When you attach the toys to the arches, the hooks must be fully closed. If you find broken or damaged parts of playmat or toys, discontinue the usage, until the problem is solved.

Do not store this playmat for a long period of time in wet environment, near sources of heat or under direct sunlight.

Playmat and toys are washable by hand in warm water up to 30°C and with mild detergent for babies' clothes.

Do not wash playmat in washing machine! Make you have rinsed the playmat and toys very well before let them dry!

Arches can be cleaned with soft damp towel and mild soap.

Do not use abrasive, bleach, alcohol or other aggressive detergents.

After cleaning or washing all parts of playmat must be fully dry before further usage or storage.

Used materials: textile – 100% cotton and 100% polyester; padding – 100% polyester.



CHIPOLINO